



# Lens Installation/Replacement For All Pro Machines

This guide will explain how to install/replace the focus lenses for all of the Pro LF lasers here at Full Spectrum Laser. Below is a picture of the laser head assembly.



Remove the air assist cone on the bottom of the assembly by unscrewing the gold screw. Once the air assist cone is removed proceed to remove the lens holder from the assembly by loosening the lens holder tensioner.



At this point the lens is accessible. Use the lens removal tool provided in the accessory kit to remove the silver screw that is holding the lens in place. There will be a washer that need be removed as well.



Once the silver screw is removed along with the washer the lens can be switched out. Take note on how the original lens is sitting in the lens holder as that is how the new lens need be installed. Once the desired lens is installed into the lens holder put the laser head assembly

back together. Use the focus ruler provided with the corresponding lens to ensure that the laser is in focus after installation.